

Video #1: iPad Essentials

iPad with Case



iPad without case



Keeping the case on is essential to protecting your device!
However, please note that the case does not protect the iPad from all falls or any damage from water.

Metal Clip



Soft Rubber Tip



Your stylus allows you to control the screen with something other than your fingertip. Hold the stylus like a pen, and use the soft rubber tip to tap what you want on the screen. You can also use the metal clip to attach it to your binder so it does not get lost.

To help avoid cracks in the screen, please do not remove the provided screen protector.

